

Product data sheet

HV gate valve, Series 140, DN 350 (ID 14") Ordering No. 14051-JE28

Description

Flange JIS 350

Actuator Pneumatic, with 3-position actuator

with position indicator

Feedthrough Rotary feedthrough

Technical data

Leak rate - Valve body $< 1 \cdot 10^{-9}$ mbar Is⁻¹

– Valve seat < 1 · 10⁻⁰ mbar ls⁻¹</p>

Pressure range $1 \cdot 10^{-8}$ mbar to 1.2 bar (abs)

Differential pressure on the gate \leq 1.2 bar

Differential pressure at opening \leq 30 mbar

Conductance (molecular flow) – Nominal 43 580 Is-1

Min. adjustable
 16 ls⁻¹

Cycles until first service – Unheated and under 200 000

clean conditions

Temperature – Valve body ≤ 150 °C

(Maximum values: depending Actuator ≤ 50 °C

(Maximum values: depending — Actuator ≤ 50 °C on operating conditions and — Position indicator ≤ 80 °C

sealing materials)

Heating and cooling rate 50 °C h⁻¹

Material (main components) – Valve body AISI 304 (1.4301)

- Mechanism AISI 304 (1.4301), AISI 301 (1.4310)

Seal – Bonnet FKM (Viton®), O-ring

– Gate
 – Actuator
 FKM (Viton®), O-ring
 FKM (Viton®), NBR

Mounting position any

Volume of pneumatic actuator 2.6 I / 0,093 ft³

Compressed air 4-7 bar / 58-102 psi

min. - max. overpressure

Compressed air connection G\(^{\mathbb{'}}\)" (\(^{\mathbb{'}}\)" NPT for USA)

- opening ≤ 6 s

Weight 127 kg / 279 lbs

Modified by:	Release date:	876970EA.DOCX
Created by: RIDO	Release date: 2020-12-14	1 of 2



Product data sheet

HV gate valve, Series 140, DN 350 (ID 14") Ordering No. 14051-JE28

Behavior in case of compressed

air pressure drop

- Valve closed valve remains closed

Valve open undefinedMiddle position undefined

Behavior in case of power failure

Valve closed depending on customer installation
 Valve open depending on customer installation
 Middle position depending on customer installation

Valve position indication visual (mechanical)

Electrical connections

Position indicator

Type Micro switch

Voltage \leq 250 V AC \leq 50 V DC

Current max. $\leq 5 \text{ A}$ $\leq 3 \text{ A}$

2		OPEN				
1 INTERMEDIATE						
_6	6 5 CLOSED					
Valve/Ventil/Vanne						
		OPEN	INTERMEDIATE	CLOSED		
(3-1-)	1,2	connected	4	= 1		
	4,3		connected	-		
Front view	6,5	12	8	connected		

Wiring diagram

Created by: RIDO	Release date: 2020-12-14	2 of 2
Modified by:	Release date:	876970EA.DOCX